

TP10KAC-DX

Two Post Clear Floor

'Bi-Symmetric' Automotive Lift

10,000 lb. Capacity
(2,500 lbs. Max Capacity per Arm)

Installation & Operation Manual



IMPORTANT!!
**READ MANUAL THOROUGHLY BEFORE INSTALLING, OPERATING,
SERVICING OR MAINTAINING LIFT**

July 2017

INDEX

PREFACE-----	PAGE 2
PRODUCT IDENTIFICATION-----	PAGE 2
SAVE THESE INSTRUCTIONS-----	PAGE 2
OWNER / EMPLOYER OBLIGATIONS-----	PAGE 3
IMPORTANT SAFETY INSTRUCTIONS-----	PAGE 4
LOCATION-----	PAGE 5
SAFETY DECALS-----	PAGE 6
IMPORTANT INFORMATION-----	PAGE 7
PRODUCT INFORMATION-----	PAGE 8
INSTALLATION-----	PAGE 11
OPERATION-----	PAGE 25
INSPECTION & MAINTENANCE INSTRUCTIONS-----	PAGE 28
EXPLODED VIEWS & PARTS LISTS -----	PAGE 31
TROUBLESHOOTING GUIDE-----	PAGE 36
WARRANTY POLICY-----	PAGE 37

PREFACE

Prior to the operation of your lift make sure that you have read the instructions thoroughly. These instructions are found in this manual. Please note that your warranty can be voided if you do not read the manual and understand its content.

If you have any questions, concerning operation, safety or application of your lift, please consult your distributor.

PRODUCT IDENTIFICATION

	
Lift Model:	TP10KAC-DX
Serial No.:	JAN 2017-XXXX
Total Capacity:	10,000 lbs.
Max. Arm Capacity:	2,500 lbs.
Date of Mfg.:	JAN XX, XXXX
Voltage:	220VAC
Amps:	20
Ph:	Single
<small>Tuxedo Distributors, LLC., 1905 N. Main, Suite C., Cleburne, TX 76033 MADE IN CHINA</small>	

**IMPORTANT
SAVE THESE INSTRUCTIONS**

OWNER / EMPLOYER OBLIGATIONS

1. The Owner/Employer shall ensure that lift operators are qualified and that they are trained in the safe use and operation of the lift using the manufacturer's operating instructions; ALI/SM10-1, **ALI Lifting it Right safety manual**; ALI/ST-10 **ALI Safety Tips card**; ANSI/ALI ALOIM-2008 (R2013), **American National Standard for Automotive Lifts - Safety Requirements for Operation, Inspection and Maintenance**; ALI/WL101 Series, **ALI Uniform Warning Label Decals/Placards**; and in the case of frame engaging lifts, ALI/LP-GUIDE, **Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts**.
2. The Owner/Employer shall establish procedures to periodically inspect the lift in accordance with the lift manufacturer's instructions or ANSI/ALI ALOIM-2008 (R2013), **American National Standard for Automotive Lifts - Safety Requirements for Operation, Inspection and Maintenance**; and the Employer shall ensure that the lift inspectors are qualified and that they are adequately trained in the inspection of the lift.
3. The Owner/Employer shall establish procedures to periodically maintain the lift in accordance with the lift manufacturer's instructions or ANSI/ALI ALOIM-2008 (R2013), **American National Standard for Automotive Lifts - Safety Requirements for Operation, Inspection and Maintenance**; and the Employer shall ensure that the lift maintenance personnel are qualified and that they are adequately trained in the maintenance of the lift.
4. The Owner/Employer shall maintain the periodic inspection and maintenance records recommended by the lift manufacturer's instructions or ANSI/ALI ALOIM-2008 R2013), **American National Standard for Automotive Lifts - Safety Requirements for Operation, Inspection and Maintenance**.
5. The Owner/Employer shall display the lift manufacturer's operating instructions; ALI/SM 10-1, **ALI Lifting it Right safety manual**; ALI/ST-10 **ALI Safety Tips card**; ANSI/ALI ALOIM-2008 (R2013), **American National Standard for Automotive Lifts - Safety Requirements for Operation, Inspection and Maintenance**; ALI/WL Series, **ALI Uniform Warning Label Decals/Placards**; and in the case of frame engaging lifts, ALI/LP- GUIDE, **Vehicle Lifting Points/Quick Reference Guide for Frame Engaging Lifts** in a conspicuous location in the lift area convenient to the operator.
6. The Owner/Operator shall provide necessary lockout/tag out means for energy sources per ANSI Z244.1-1982 (R1993), **Safety Requirements for the Lockout / Tag out of Energy Sources**, before beginning any lift repairs and maintenance.

7. The Owner/Employer shall not modify the lift in any manner without the prior written consent of the manufacturer.

IMPORTANT SAFETY INSTRUCTIONS

When using this lift, basic safety precautions should always be followed, including the following:

1. Do not raise a vehicle on the lift until the installation is completed as described in this manual.
2. Always position the arms and adapters properly out of the way before pulling the vehicle into, or out of the bay. Failure to do so could damage the vehicle and/or the lift.
3. Do not overload the lift. The capacity of the lift is shown on cover of this document and on the lift's serial number tag.
4. Note that the removal or installation of some vehicle parts may cause a critical load shift in the center of gravity and may cause the vehicle to become unstable. Refer to the vehicle manufacturer's service manual for recommended procedures.
5. Positioning the vehicle is very important. Only trained technicians should position the vehicle on the lift. Never allow anyone to stand in the path of the vehicle as it is being positioned and never raise vehicle with passengers inside.
6. Position the arms to the vehicle manufacturer's recommended pickup points. Raise the lift until contact is made with the vehicle. Make sure that the arms have properly engaged the vehicle before raising the lift to a working height.
7. Keep everyone clear of the lift when the lift is moving, the locking mechanism is disengaged, or the vehicle is in danger of falling.
8. Unauthorized personnel should never be in the shop area when the lift is in use.
9. Inspect the lift daily. The lift should never be operated if it has damaged components, or is malfunctioning. Only qualified technicians should service the lift.
10. Replace damaged components with manufacturer's parts, or equivalent.
11. Keep the area around the lift clear of obstacles.
12. Never override the self-returning lift controls.
13. Use safety stands when removing or installing heavy vehicle components.
14. Avoid excessive rocking of the vehicle when it is on the lift.

15. To reduce the risk of personal injury, keep hair, loose clothing, fingers, and all body parts away from moving parts.
16. To reduce the risk of electric shock, do not use the lift when wet, do not expose the lift to rain.
17. To reduce the risk of fire, do not operate equipment in the vicinity of open containers of flammable liquids (gasoline).
18. Use the lift only as described in this manual, use only manufacturer's recommended attachments.
19. Unusual vehicles, such as limousines, RV's, and long wheelbase vehicles, may not be suitable for lifting on this equipment. If necessary, consult with the manufacturer or the manufacturer's representative.
20. The troubleshooting and maintenance procedures described in this manual can be done by the lift's owner/employer. Any other procedure should only be performed by trained lift service personnel. These restricted procedures include, but are not limited to, the following: cylinder replacement, carriage and safety latch replacement, leg replacement, over-head structure replacement.
21. Anyone who will be in the vicinity of the lift when it is in use should familiarize themselves with following Caution, Warning, and Safety related decals supplied with this lift, and replace them if they are illegible or missing.

WARNING!! Failure by purchaser to provide the recommended mounting surface could result in unsatisfactory lift performance, property damage, or personal injury.

For additional safety instructions regarding lifting, lift types, warning labels, preparing to lift, vehicle spotting, vehicle lifting, maintaining load stability, emergency procedures, vehicle lowering, lift limitations, lift maintenance, good shop practices, installation, operator training and owner/employer responsibilities, please refer to “**Lifting It Right**” (ALI/SM) and “**Safety Tips**” (ALI/ST) and **vehicle lift points for service garage lifting SAE J2184.**

For additional instruction on general requirements for lift operation, please refer to “Automotive Lift-Safety Requirements for Operation, Inspection and Maintenance” (ANSI/ALI ALOIM).

Installation shall be performed in accordance with ANSO/ALI ALIS, Safety Requirements for Installation and Service of Automotive Lifts.

LOCATION

This lift has been evaluated for **INDOOR USE ONLY** with an operating ambient temperature range of 5 - 40°C (41-104°F)




ATTENTION! This lift is intended for **indoor installation only**. It is prohibited to install this product outdoors. Operating environment temperature range should be 41 – 104 °F (5 – 40 °C). **Failure to adhere will result in decertification, loss of warranty, and possible damage to the equipment.**

SAFETY DECALS

These Decals Must Be Applied to Lift.

NOTE: SOME IMAGES IN THIS MANUAL ARE GENERIC AND MAY NOT RESEMBLE THE LIFT YOU HAVE PURCHASED.

REFERENCE: AUTOMOTIVE LIFT INSTITUTE, Inc.



NOTICE If attachments, accessories, or configuration modifying components used on this lift are located in the load path and affect operation of the lift, affect the lift electrical listing, or affect intended vehicle accommodation; and if they are not certified for use on this lift, then the certification of this lift shall become null and void. Contact the participant for information pertaining to certified attachments, accessories, or configuration modifying components.

www.auolift.org

© 2011 by ALI, Inc. ALI/WLSIA01

CAUTION
 RELEASE ALL LATCHES
 BEFORE LOWERING LIFT
 MAXIMUM CAPACITY
10,000 LBS.

IMPORTANT INFORMATION

Please deliver this manual to the lift owner and/or operator along with all other documentation provided with the lift. Failure to operate this equipment as intended may cause injury or death.

1. Read this manual thoroughly before **installing, operating, or maintaining this lift.**
2. This lift is designed for indoor use only, and **should not** be installed in a pit or depression.
3. The floor on which the lift is to be installed must be **4-1/4” minimum thickness concrete, with a minimum compressive strength of 3,000 psi.**
4. The lift has **specific electrical requirements** as described in the Installation Instructions section of this manual.
5. This lift has a **minimum ceiling height requirement** as described in the Installation Instructions section of this manual.
6. It is **recommended that the lift to be located 10’ – 12’ from the nearest obstruction in front of the lift and 2’ – 3’ from the nearest obstruction on each side of the lift.**
7. Failure by the owner to provide the **recommended shelter, mounting surface, electrical supply, and ceiling height** could result in unsatisfactory lift performance, property damage, or personal injury.
8. The operation of the lift **is permitted by authorized person only.**
9. Lift buyers **are responsible for any special regional structural and/or seismic anchoring requirements** specified by any other agencies and/or codes such as the Uniform Building Code (UBC) and/or International Building Code (IBC). When required, it is recommended to contact a qualified engineer to address the specific UBC and/or IBC code requirements.

NOTICE

If attachments, accessories, or configuration modifying components used on this lift are located in the load path and affect operation of the lift, affect the lift electrical listing, or affect intended vehicle accommodation; and if they are not certified for use on this lift, then the certification of this lift shall become null and void. Contact the participant for information pertaining to certified attachments, accessories, or configuration modifying components.

www.auolift.org

© 2011 by ALI, Inc.

ALI/WLSIA01


1. PRODUCT INFORMATION

1.1 Product Description

The TP10KAC-DX 2-post hydraulic lift is a surface mounted, frame contact lift incorporating the latest safety technologies. Designed and manufactured for a lifting capacity of 10,000 lbs. (Max 2,500 lbs. per Lifting Arm) and is fully capable for lifting vehicles, vans and light trucks by safely holding them in an elevated position. The TP10KC-DX also incorporates the *Bi-Symmetric* feature, which allows the Arms to be configured for both asymmetrical & symmetrical lifting configurations.

The TP10KC-DX 2-post hydraulic lift consists of a fixed structural unit (Crossbeam and Columns), the mobile units (Carriages and Lift Arms), and the Hydraulic Power System and Safety devices.

- A. Crossbeam
- B. Column
- C. Carriage
- D. Lifting Arm
- E. Power Unit
- F. Overhead Safety Shut-Off Bar
- G. Single Point Safety-Latch Release



1.2 Technical Data

Capacity	10,000 lbs. (Max 2,500 lbs. per Arm)
Height Overall	144"
Width Overall w/ Power Unit	145-1/2"
Max Lifting Height	71"
Max Lifting Height w/ Tallest Adaptor	76-1/2"
Width Between Columns	116"
Min Pad Height	4"
Drive Thru Clearance	104"
Front Arm Reach – Min / Max	23" – 45"
Rear Arm Reach – Min / Max	41" – 57"
Electrical Power	220V, 20 Amp, 1 Phase
Max Hydraulic Pressure	3,050 PSI

Figs. 1 & 2 Elevation & Floor Layout




Fig. 1 - Elevation View



POWER UNIT MUST BE INSTALLED ON THE PASSENGER SIDE. FAILURE TO DO SO CAN RESULT WITH INTERFERECE BETWEEN THE POWER UNIT AND SHORT SWING ARM, THUS CAUSING DAMAGE TO POWER UNIT.

Bi-Symmetric (Asymmetric & Symmetric) Configurations




Fig. 2 - Floor Layout

2. INSTALLATION

2.1 Site Selection

The hydraulic lift is designed only for indoor use. Application in a room with explosion hazard is not permitted. Setting in a wet place, a car wash center for instance, is prohibited.

2.2 Surface Condition / Foundation & Anchoring

The 2-post hydraulic lift should be installed on level ground. The foundation must be 4-1/4" minimum thickness concrete, with a minimum compressive strength of 3,000 psi. Failure to meet the foundation requirement may cause the lift instability or personal injury. Installing on asphalt, soft clay floor or near the expansion gap is prohibited.


FOUNDATION and ANCHORING REQUIREMENTS

1. Concrete shall have compression strength of at least 3,000 PSI and a minimum thickness of 4-1/4" in order to achieve a minimum anchor embedment of 3-1/4". NOTE: When using the standard supplied 3/4" x 5-1/2" long anchors, if the top of the anchor exceeds 2-1/4" above the floor grade, you DO NOT have enough embedment.
2. Maintain a 6" minimum distance from any slab edge or seam. Hole to hole spacing should be a minimum 6" in any direction. Hole depth should be a minimum of 4-1/4".
3. DO NOT install on asphalt or other similar unstable surface. Columns are supported only by anchoring to floor.
4. Using the horseshoe shims provided, shim each column base as required until each column is plumb. If one column has to be elevated to match the plane of the other column, full size base shim plates should be used. Torque anchors to 110 ft-lbs. Shim thickness MUST NOT exceed 1/2" when using the 5-1/2" long anchors provided with the lift.
5. If anchors do not tighten to 110 ft-lbs. installation torque, replace the concrete under each column base with a 4' x 4' x 6" thick 3,000 PSI minimum concrete pad keyed under and flush with the top of existing floor. Allow concrete to cure before installing lifts and anchors (typically 2 to 3 weeks).

ANCHORING TIPS

1. Use a concrete hammer drill with a carbide tip, solid drill bit the same diameter as the anchor, 3/4" - (.775 to .787 inches diameter). Do not use excessively worn bits or bits which have been incorrectly sharpened.
2. Keep the drill in a perpendicular line while drilling.
3. Let the drill do the work. Do not apply excessive pressure. Lift the drill up and down occasionally to remove residue to reduce binding.
4. Drill the hole to depth of 2" deeper than the length of anchor. NOTE: Drilling thru concrete (recommended) will allow the anchor to be driven thru the bottom of foundation if the threads are damaged or if the lift will need to be relocated.
5. For better holding power blow dust from the hole.
6. Place a flat washer and hex nut over threaded end of anchor, leaving the nut almost flush with the top of the anchor bolt. Carefully tap anchor into hole. Do not damage threads. Tap anchor into the concrete until nut and flat washer are against base plate. Do not use an impact wrench to tighten! Tighten the nut, two or three turns on average after the concrete has cured (28-day cure). If the concrete is very hard only one or two turns may be required.

FOUNDATION and ANCHORING REQUIREMENTS, Fig 3



2.3 Tools & Equipment Required

- 12 quarts of Non-Detergent / Non-Foaming Hydraulic Oil - SAE-10, AW 32 or equivalent
- Chalk line and 12' Tape Measure
- Concrete hammer drill with 3/4" bit
- 11/16" open end wrench
- 3/4" open end wrench
- Torque wrench
- 15/16" deep socket or wrench
- 1-1/8" socket
- 13/16" open end wrench
- Level (18" minimum length)
- Vise grips
- Tape measure
- Funnel
- Hoist or Forklift (optional)
- Two 12' step ladders
- 1/4" drive ratchet with 5/16" socket

2.4 Installation Procedure

1. Read this manual thoroughly before Installing, Operating, or Maintaining this lift.

2. Site Evaluation and Lift Location

- A. Always use an architect's plan when provided. Before unpacking the lift entirely, determine if the site is adequate for the lift model being installed see figures 1 & 2 for typical bay layout and ceiling height requirements. It is recommended to have 144" (12') minimal ceiling height.
- B. Snap chalk lines to identify the lift's centerline.
- C. Snap a chalk line parallel to the lift's centerline, **spaced 9.00"** toward the rear of the bay. This line represents the back edge of the column bases.
- D. Snap chalk lines parallel to the lift's centerline **spaced 68-7/8" to the left and 68-7/8" to the right**. These lines represent the **APPROXIMATE** outside edges of the column bases.



DO NOT USE THESE LINES TO POSITION THE COLUMNS, FOLLOW THE INSTRUCTIONS IN THIS MANUAL.

3. Unpack the Lift

- A. Remove the swing arms, bolt box, power unit box, and overhead beam.
- B. Save all packing hardware, as these components are necessary to complete the installation.
- C. Remove the 1/2" bolts from the uprights which hold the two columns together.
- D. Remove the upper column. Do not stand the columns up now but lay the columns with their flat backs on the floor.

4. Attach Cylinder Mounts

- A. Connect cylinder mounts to top of each column using 4ea 1/2" x 1-3/4" bolts, washers and nuts provided as shown in figures 4a & 4b.




Fig. 4a




Fig. 4b

5. Install Hydraulic Cylinders

- A. Install the cylinder to the cylinder mounts (uprights) with **9/16" x 4-1/2" pins, cylinder bushings (spacer) washers, and snap rings, as in figure 5a**. The hose connecting port near the other end of the cylinder should be positioned pointing to the column's opening. (Fig. 5b)
- B. Bolt the cylinder rods to the carriages. (Fig. 5c) **NOTE: MAKE SURE SNAP RING ON CYLINDER ROD IS IN SECURED IN GROOVE.**




Fig. 5a



Fig. 5b



Fig. 5c

DO NOT HOLD THE CYLINDER ROD IN A WAY THAT COULD DAMAGE THE FINISH. CYLINDER LEAKS CAUSED BY DAMAGED RODS ARE NOT COVERD UNDER WARRANTY.

6. Columns Positioning & Main Side Column Anchoring

- A. **Carefully stand up the Main side column (w/ power unit bracket) & Off side column**, position the columns where they are to be secured. Ensure column's openings are facing each other.



THE MAIN SIDE COLUMN MUST BE POSITIONED TO BE ON THE PASSENGER SIDE OR RIGHT SIDE WITH THE VEHICLE HEADED FORWARD. THE DISTANCE BETWEEN COLUMN'S BACK EDGE TO WALL, SHOULD BE AT LEAST 2 FEET FOR SAFETY.

- B. Using the column base as a template, drill the anchor bolt holes for the **Main side column only!** (Refer to FOUNDATION REQUIREMENTS & ANCHORING TIPS ON PAGES 12 & 13)
NOTE: DO NOT ANCHOR OFF SIDE COLUMN AT THIS TIME!
- C. Install the anchor bolts, assemble washers & nuts onto the anchor bolts. Thread the nuts onto the anchors bolts where the tops of the nuts are just above the top of the anchor bolts. Carefully tap the anchor bolts into the concrete until the washer rests against the base plate. **Ensure not to damage threads.**
- D. Using a level, plumb the Main side column both side to side and front to back. Shim the leg as necessary using the Shims provided. Tighten anchor bolts to 110 ft. lbs. as noted on page 9. Re-check to ensure column is plumb.

NOTE: REFER TO 'FOUNDATION & ANCHOR REQUIREMENTS' IF MORE THAN 1/2" OF SHIMS ARE REQUIRED.

- E. Ensure Off side column is in the correct location. **DO NOT DRILL HOLES FOR ANCHORS at this time.**

7. Install Overhead Limit Switch & Overhead Beam (Figs. 6a, 6b & 6c)

- A. Install overhead limit switch assembly to overhead beam, using 2ea 1/4"-20 Bolt & Lock Nuts as shown in figs 6a, 6b & 6c.
- B. Slide end of padded bar (without a mounting hole) through the slot in the overhead switch assembly. Connect the padded bar to the inside hole in the overhead beam using a spacer and 1/4"-20 Bolt & Lock Nut




Fig. 6a




Fig. 6b

**Position Overhead Limit Switch
Assembly on same side as power unit.**




Fig. 6c

8. Install Overhead Beam

- A. Install cylinder mounts (uprights) using 2ea 1/2" x 1-3/4" bolts, washers & nuts on each end, (Figs. 7a, 7b, 7c). **NOTE: ENSURE OVERHEAD LIMIT SWITCH ASSEMBLY IS ON THE MAIN SIDE COLUMN SIDE.**




Fig. 7a




Fig. 7b



Fig. 7c

9. Anchoring Off Side Column

- A. Using a level, check the alignment and plumbness of the entire structure. Plumb the off side column both side to side and front to back.
- B. The base of the column may vary from the preliminary layout, as it is more important that the column be perpendicular to the floor and parallel to the other column.
- C. Install the anchor bolts and shim the base as described in Step #6



10. Equalization Cable Routing

- A. The carriages should be resting on the same column latches for proper equalization. Ensure to measure the height above the baseplate to each carriage. The measurement should be within 3/8" of each other.



Fig. 8a




Fig. 8b

- B. Using the diagrams, route the equalization cables according to figs. 8a, 8b & 8c (Cable Routing Diagram next page) from carriage to carriage through the cable rollers. Secure to carriages using Nylon Hex Nuts & Washers. Ensure that cables are not crossed together. Take out slack but **DO NOT TIGHTEN CABLES AT THIS TIME.**
- C. After equalizations cables are routed and connected to carriages, take out the slack in both cables by turning down the nuts on top of each carriage top. Use vise grips to hold the cable end, but be very careful not to damage the threads.
NOTE: CARRIAGES MUST REMAIN AT THE SAME COLUMN LOCK HEIGHT POSITION WHILE CABLES ARE BEING TIGHTENED. FAILURE TO DO WILL CAUSE THE CARRIAGES SAFETY LATCHES TO BE OUT OF SYNC.
- D. Alternately tighten the cable nuts at both carriages until the cables are tightened. The correct tension in the cables are indicated by being able to pull the cables together with approximately 15 lbs. effort at midpoint in the column. If the cables are installed correctly, both carriages will raise together.

EQUALIZATION CABLE ROUTING DIAGRAM




Fig. 8c - Cable Routing Diagram

11. Install the Hydraulic Fittings, Hoses and Return Lines



When attaching hydraulic fittings with pipe threads to the cylinders use Teflon tape. **DO NOT start the Teflon tape closer than 1/8"** from the end of the fitting. Failure to comply may cause damage to the Hydraulic system.



When tightening connections with flared (JIC) fittings, always follow the following tightening instructions. Failure to follow the below instructions may result in cracked fitting and/or leaks.


- Use the proper size wrench.
- The nut portion of the fitting is the only part that should turn during tightening. The flare seat **MUST NOT** turn.
- Screw the fittings together hand tight.
- Rotate the nut portion of the fitting 2-1/2 hex flats.
- Back the fitting off one full turn.
- Again, tighten the fitting hand tight, and then rotate the nut portion of the fitting **2-1/2 hex flats**.

A. Fittings & Hoses Connections:

1. First screw on the hose fitting connectors on the cylinder's lower end ports. (Fig. 9a)
2. Connect the longest hose from the cylinder in Off side column to the top of Main side column. Remember to route the hose through the hook on cross beam. (Fig. 9b & 9c)
3. Then from the T-fitting inside column, connect the shortest length hose directly down to the main inside cylinder connector. (Fig. 9d)
4. Another middle length hose from the T-fitting goes to the motor pump through a hole on the side of the column. (Fig. 9d)
5. Pull hoses upward taking out any slack between the cylinder fitting ports and the cylinder mounts. Secure hoses to main side cylinder with wire tie around the T-Fitting and the cylinder. **The T-Fitting should be positioned to aim directly out through the grommet, fig 9d.** Secure Offside hose to cylinder at the same height with a wire tie.




Fig. 9a



Off Side Column

Fig. 9b



Main Side Column

Fig. 9c




Fig 9d

B. Return Line Connection (blue plastic tubing)

1. Screw in an elbow air-line fitting on the top end of the off side cylinder (Fig. 9b).
2. Screw in another T air-line fitting on the top end of main side cylinder also. (Fig. 9c)
3. Connect the return line from off side cylinder to main side cylinder with press-lock fittings. The tubing section off other end of T-fitting will be routed to power unit.

12. Mounting Power Unit

- A. Mount on the motor pump using 5/16" x 1-1/4" bolts and nylon nuts provided in the bolt box to Main side column.
- B. Connect the 'blue' Return Line to the 90 degree air fitting, on side of valve block as shown in (Fig 10)
- C. Connect the hydraulic hose to the 90 degree fitting, on side of valve block, as shown in (Fig 10).



Fig. 10

13. Latch-Release Cable Wiring & Accessories mounting.

- A. Mount the safety latch device on each column as shown in (Fig. 11a & 11b)




Fig. 11a

Off Side Column




Fig. 11b

Main Side Column

B. Mount the Cable Pulley and Support Bracket on the top of the Columns. (Fig. 11c)



Fig. 11c

C. Route and adjust the cable tension so that when the handle is pressed down, both latches will be released.

D. Install covers for both latch devices on Off Side & Main Side columns, using the provided screws. (Figs. 12a & 12b)



Fig. 12a
(Off Side Column)




Fig. 12b
(Main Side Column)

14. Install Arm Restraints & Lifting Arms

- A. Position the arm restraint gears with pin against the bottom of the arms in the orientation shown in Fig.13a. Attach the gears to the arms with bolts. Do not tighten at this time.




Fig. 13a




Fig. 13b

- B. Position the arm restraint pawls on the carriage to mate with the gears on the arms.
C. Install the swing arms to the carriages using the pins, as shown in Fig. 13a & b. Secure pin to carriage with clip at bottom of pin.

Suggestion: Position Long Arms to rear or 'drive-in' end of the lift, with Short Arms (L&R) to the front.



DON'T FORCE THE GEARS, IT MAY BE NECESSARY TO PULL UP ON THE RESTRAINT ACTUATOR PIN IN ORDER TO INSTALL THE SWING ARM PIN.

- D. Tighten the arm restraint gear bolts to 30 – 34 ft. lbs.
E. Assemble the arm extensions & lifting pads. Limit arm extensions with bolt & nuts. (Fig.14a & 14b)



Fig. 14a (Front Arm)




Fig. 14b (Rear Arm)

15. Filling Reservoir Tank.

- A. Remove the fill level screw of the power unit tank. Fill it with Non-Detergent / Non-Foaming Hydraulic Oil - SAE-10, AW 32 or equivalent, until fluid reaches the bottom of the screw hole. Replace the fill screw.

16. Lubricate the four inside corners of both columns with heavy duty grease.

17. Electrical Connection to Power Unit & Overhead Limit Switch

- A. Have a certified electrician make the electrical connection from power supply to the power unit. Use separate circuit for each power unit, as shown below in **(Fig. 15)**.
- B. Have a certified electrician make the electrical connection for the overhead limit switch to power unit's switch box, as shown in **(Fig. 15)**.




Fig. 15



Electrical Wiring must comply with local code. Protect each circuit with time delay fuse or circuit breaker. For 208V-230V single phase, use 20 amp fuse.

Never operate the motor in line voltage less than 208VAC as motor damage may occur.

18. Testing

NOTE

- ❖ **In this step A, there is no load on the lift.**
- ❖ **Cycle up and down must be with interval rest of 2 mins.**

- A. Without a load, raise the lift empty to the top of its travel and lower it to the floor three (3) times to remove the remaining air from the hydraulic system.
- B. The latches should click close together as the lift is being raised. If not, adjust cables for proper equalization and tightness.
- C. When the carriages are lowered onto the locks, the Latch Release Handle should NOT be capable of being pulled down. Prior to lowering the carriages, always raise up enough to free the latches, then pull down the latch release handle to unlock the carriages to lower. Ensure both latches properly release.
- D. The first time a vehicle is placed on the lift, raise it no higher than three feet. Lower the vehicle onto the safety latches. Raise the lift a few inches and pull latch release lever then lower the vehicle to the floor.
- E. Raise the vehicle to full height and lower the carriages onto the safety latches. Lower the vehicle to the floor.
- F. After cycling the lift ten times with a vehicle on it, recheck the tightness of the anchors to at least 110 ft-lbs.

The Lift is now ready for Operation.

3. Operation

BE SURE TO READ AND FAMILIARIZE YOURSELF WITH THE SAFETY INSTRUCTIONS AT THE BEGINNING OF THIS MANUAL. FAILURE TO FOLLOW SAFETY INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.

3.1 Operating Instructions



BE SURE TO READ AND FAMILIARIZE YOURSELF WITH THE SAFETY INSTRUCTIONS AT THE BEGINNING OF THIS MANUAL. FAILURE TO FOLLOW SAFETY INSTRUCTIONS MAY RESULT IN PROPER DAMAGE, PERSONAL INJURY OR DEATH.



TO AVOID PERSONAL INJURY AND/OR PROPERTY DAMAGE, PERMIT ONLY TRAINED PERSONNEL TO OPERATE LIFT. AFTER REVIEWING THESE INSTRUCTIONS, GET FAMILIAR WITH LIFT CONTROLS BY RUNNING THE LIFT THROUGH A FEW CYCLES BEFORE LOADING VEHICLE ON THE LIFT.



ALWAYS LIFT THE VEHICLE USING ALL FOUR ADAPTERS. NEVER RAISE JUST ONE END, ONE CORNER, OR ONE SIDE OF VEHICLE.

3.1.1 Lift Preparation


Lift arms must be fully lowered and service bay clear of all personnel before the vehicle be brought into the bay. Configure Swing arms to drive-thru position.

3.1.2 Vehicle Positioning

- a. Positioning the vehicle between columns.
- b. Adjust lift arms so that the vehicle is positioned with the center of gravity between the pads. Make sure the arm restraints are fully engaged.
- c. Raise the lift by pressing the lifting button on power unit until the lifting pad adaptors contact underside of the vehicle.
- d. Make sure the vehicle is secured.

3.1.3 Loading Lift

Swing arms under vehicle and position adapters at vehicle manufacturer's recommended lift points. Use intermediate, high step, or optional adapters for under body clearance when required.



Also see Vehicle Lifting Points on Page 27 for additional information.

3.1.4 To Raise Lift

- a. Push START button of the motor pump.
- b. Stop before arms making contact with vehicle. Check arm restraint pins for engagement. If required, slightly move arm to allow restraint gear and pawl to match. **DO NOT** hammer pin down, as this will damage the restraint gear teeth.
- c. Raise vehicle until the wheels slightly clear the floor, then release the START button.

- d. Check support adapters for secure contact at vehicle manufacturer recommended lift points.
- e. Continue to raise to desired height only if vehicle is secure on lift. Then release the START button.
- f. DO NOT go under vehicle if all four adapters are not in secure contact at vehicle manufacturer recommended lift point.
- g. Repeat complete spotting, loading and raising procedures if required.
- h. Press down the hydraulic pressure release lever on the motor pump to lower the vehicle into the locking position. The locking latches are engaged.



DO NOT GO UNDER VEHICLE IF LOCKING LATCHES ARE NOT ENGAGED.



BEFORE ATTEMPTING TO LIFT PICKUP TRUCKS OR OTHER TRUCK FRAME VEHICLES, BE SURE THAT:

- **Vehicle frame is strong enough to support its weight and has not been weakened by modification or corrosion.**
- **Vehicle individual axle weight does not exceed one-half lift capacity.**
- **Adapters are in secure contact with frame at vehicle manufacturers recommended lift point.**
- **Vehicle is stable on lift**
- **The overhead switch bar will contact the highest point on the vehicle**

3.1.5 While Using Lift

- a. Avoid excessive rocking of vehicle while on lift.
- b. Always use safety stands as needed or when removing or installing heavy components.

3.1.6 To Lower Lift

- a. Remove all tools or other objects from lift area
- b. Press START button a few seconds to raise up a little. Then pull down on the single point, latch-release handle with one hand, while at the same time pressing down on the power unit's pressure-release lever with the other hand.



REMAIN CLEAR OF LIFT WHEN LOWERING VEHICLE. OBSERVE PINCH POINT WARNING DECALS.

3.1.7 Unloading Lift

After the lift is lowered down onto the ground, remove adapters from under vehicle and swing arms to full drive-thru position before moving vehicle out.



IF LIFT IS NOT OPERATING PROPERLY, DO NOT USE UNTIL ADJUSTMENT OR REPAIRS ARE MADE BY QUALIFIED LIFT SERVICE PERSONNEL.


Vehicle Lifting Points

Some vehicles may have the manufacturer's Service Garage Lift Point locations identified by triangle shape marks on its undercarriage (reference SAE J2184). There may also be a label located on the right front door lock face showing specific vehicle lift points. If the specific vehicle lift points are not identified, please refer to the "Typical Lift Points" illustration below or the ALI/LP Guide - Vehicle Lifting Points / Quick Reference Guide included with your lift. Consider center of gravity, contents of vehicle and weight shifting before operating.


Make sure the vehicle is neither front nor rear heavy. If the specific vehicle lift points are not identified, or if the vehicle has additional or uniquely positioned payload, have a qualified person calculate the vehicle center of gravity or have the vehicle center of gravity determined at a vehicle scale. Load the vehicle with the center of gravity midway between adapters.

Unusual vehicles, such as limousines, RV's, and long wheelbase vehicles, may not be suitable for lifting on this equipment.


If necessary, consult with your iDEAL Automotive Equipment representative or contact the vehicle manufacturer.




Pickup Truck



Unitized Body



Perimeter Frame



Stub Frame

4. Inspection & Maintenance Instructions

Contact your service provider for instruction before starting up if you are not completely familiar with automotive lift maintenance procedures. Only qualified personnel can perform maintenance on this equipment. Any failure in operation may cause personal injury or death.

Daily

- ❖ Always keep bolts tight. Check periodically.
- ❖ Always keep lift components clean.
- ❖ Always if oil leakage is observed, contact your service provider.
- ❖ Check cables and sheaves for wear every day. Replace worn or broken parts with lift manufacturer's parts, or their equivalent.

Monthly

- ❖ Check equalizer cable tension.
- ❖ Lubricate locking latch shafts. Push latch handle several times for oil to penetrate joints.
- ❖ Lubricate the four inside corners of the columns with heavy duty bearing grease.
- ❖ With lift lowered, check the hydraulic fluid level. If necessary add oil as described in the Installation Instruction section of this manual
- ❖ Check carriage latch synching: Latches should click at the same time. If necessary adjust equalization cables.
- ❖ Check tightness of all bolts.
- ❖ Check the nuts for tightness every week for the first month, and every month afterwards.

Every 3 Months

- ❖ Check anchor bolts for tightness. Anchors should be torque to 110 ft-lbs.
- ❖ Check and clean the oil filter

Every 6 Months

- ❖ Check fluid level of lift power unit and refill if required.
- ❖ If Lift stops short of full rise or chatters, contact your service provider.
- ❖ Replace all caution, warning or safety related decals on the lift if unable to read or missing reorder labels from service provider.

Also, see ANSI/ALI ALOIM booklet for periodic Inspection Checklist and Maintenance Log Sheet.

ALWAYS REPLACE WORN PARTS WITH GENUINE, AUTHORIZED PARTS.

For Parts & Service Assistance

Please contact iDEAL Automotive Equipment @ Toll Free: 877-588-9337

(Also see Additional Information next two pages)


WIRE ROPE INSPECTION



- Wire ropes are critical to the safe and reliable performance of your lift.
- Cables are expendable items and should be replaced as a set.

CABLE CONDITION GUIDE (Maximum Allowable Cable Necking)


Nom. Cable Diameters	Max. Reduction in Diameter
Up to 5/16"	1/64"
3/8" to 1/2"	1/32"



Typical Good Cable



Cable with Necking



Cable with Corrosion



Cable with Broken Wires

WIRE ROPE REPLACEMENT CRITERIA



If any cable is found to be in need of replacement, the entire cable set, pulleys and safety rollers, must be replaced immediately. See Cable Condition Guide.

The Wire Rope MUST be replaced if One or More of the Following Criteria Are Met:

- More than six (6) randomly distributed broken wires in one rope *lay or 6xd length.
- More than three (3) broken wires in one strand in one rope *lay or 6xd length.
- Three (3) or more broken wires at rope terminations.
- One outer wire broken at the point or contact with the core of the rope which has worked its way out of the rope structure and protrudes or loops out from the rope structure.
- Heavy rusting, corrosion, or pitting. A light surface corrosion on outer wires is normal.
- Wear or scraping of one-third (1/3) of the original diameter of outside individual wires.
- Excessive stretch. It is normal for new cable to require adjustment during "break-in," after which small periodic adjustments may be required. However, if a cable that has been in service for 6 months should suddenly require frequent adjustments or has used all the cable adjustments available, all cables must be replaced immediately.
- Deformed strands, kinking, crushing, bird-caging, or any other damage or distortion of wire rope structure.
- Variations in diameter (necking) or any change from normal appearance.
- Reductions from nominal diameter of more than 1/32" (for cables 3/8" to 1/2" diameter inclusive.)
- End attachments cracked, deformed or worn.

* Lay is the distance measured, parallel to the rope axis, in which a single strand makes one complete turnaround the rope axis, or the wires make a complete turnaround the axis of the strand.

Also, reference ANSI/ALI ALOIM standard for more information on wire rope cable inspection.

Emergency Operation

(If Lift Becomes Inoperable In Raised Position)

If the lift becomes inoperable in the raised position, wait until electrical power is restored to the lift before attempting to lower the vehicle.




DO NOT LOOSEN OR REMOVE HYDRAULIC CONNECTIONS OR FITTINGS UNDER PRESSURE. SERIOUS INJURY OR DEATH COULD OCCUR.

If it is crucial for reasons of safety that the vehicle be lowered, please **DO NOT** attempt to do so on your own without first contacting your local authorized service representative or distributor, who can verbally walk you through the process or assist, in person, where necessary.

For assistance, please contact iDEAL Automotive Equipment @ Toll Free: 877-588-9337

5. Exploded View / Parts List



Parts List

For Parts & Service Assistance

Please contact iDEAL Automotive Equipment @ Toll Free: 877-588-9337

ITEM	Tux P/N	M-Ref P/N	DESCRIPTION	QTY
1-1	TP10KAC-DX-001.1	SJ12-01000-A00	Offside Column	1
2	TP11KC-DX-002	5105-08012-000	Screw, M8 x 12mm	16
3	TP11KC-DX-003	SJ12-00018-A00	Height Adaptor 2"	4
4	TP11KC-DX-004	SJ12-00019-A00	Height Adaptor 4"	4
5	TP11KC-DX-005	5110-06012-000	Screw, M6 x 12mm	24
6	TP11KC-DX-006	SJ12-00005-000	Roller, D30 x 10mm	3
7	TP11KC-DX-007	SJ12-00015-000	Pin #1	3
8	TP11KC-DX-008	5404-15012-000	Cotter Pin, D1.5 x 12mm	3
9	TP11KC-DX-009	SJ12-00010-000	Offside Cover #2	1
10	TP11KC-DX-010	5302-00006-000	Flat Washer, D6	8
11	TP11KC-DX-011	SJ12-00008-000	Small Bracket	1
12	TP11KC-DX-012	5103-06020-000	Bolt, M6 x 20mm	2
13	TP11KC-DX-013	5202-00006-000	Nut, M6	2
14	TP11KC-DX-014	SJ12-00006-000	Bolt, D12 x 40mm	2
15	TP11KC-DX-015	5202-00008-000	Nut, M8	2
16	TP11KC-DX-016	5114-06010-000	Threaded Pin, M6 x 10mm	4
17-1	TP10KAC-DX-017.1	SJ12-05001-000	Offside Bracket	1
18	TP11KC-DX-018	SJ12-00016-000	Spring #2	2
19-1	TP10KAC-DX-019.1	SJ12-06000-000	Safety Latch	2
20	TP11KC-DX-020	SJ12-00004-000	Spring #1, D35 x D2.5	2
21-1	TP10KAC-DX-021.1	SJ12-00001-000	Latch Shaft, D20 x 92mm	2
22	TP11KC-DX-022	5202-00014-000	Nut, M14	12
23	TP11KC-DX-023	5302-00014-000	Washer, D14	28
24	TP11KC-DX-024	5302-00020-000	Flat Washer, D20	6
25	TP11KC-DX-025	SJ01-00032-000	Bearing	6
26	TP11KC-DX-026	SJ01-00007-000	Pulley Shaft	2
27	TP11KC-DX-027	SJ01-00033-000	Pin	6
28	TP11KC-DX-028	SJ01-00001-000	Cable Pulley	6
29	TP11KC-DX-029	SJ01-00029-000	Pin	2
30	TP11KC-DX-030	SJ01-05000-000	Overhead Crossbeam	1
31	TP11KC-DX-031	5103-14045-000	Bolt, M14 x 45mm	12
32	TP11KC-DX-032	5206-00008-000	Lock Nut, M8	5
33	TP11KC-DX-033	SJ01-00011-000	Overhead Shut-Off Bar	1
34	TP11KC-DX-034	SJ01-00014-000	T-Fitting	1
35	TP11KC-DX-035	SJ12-04000-000	Cylinder Mount Bracket	2
36	TP11KC-DX-036	SJ12-00003-000	Large Bracket	2
37	TP11KC-DX-037	SJ01-00015-000	Return Line #2	1
38-1	TP10KAC-DX-038.1	SJ12-02000-A00	Mainside Column	1
39	TP11KC-DX-039	SJ01-00017-000	Rubber Gromit	1
40	TP11KC-DX-040	SJ12-00009-000	Mainside Cover #1	1
41	TP11KC-DX-041	SJ12-00011-000	Handle Knob, D40 x M10	1
42	TP11KC-DX-042	SJ12-00013-000	Latch Release Cable, 306"	2
43	TP11KC-DX-043	SJ12-00007-000	Latch Release Handle	1
44-1	TP10KAC-DX-044.1	SJ12-00014-000	Spacer #2	2
45	TP11KC-DX-045	SJ01-00019-000	Hydraulic Hose, 71"	1
46	TP11KC-DX-046	SJ01-00016-000	Hydraulic T-Fitting	1

47	TP11KC-DX-047	SJ01-00006-000	Hydraulic Hose, 207"	1
48	TP11KC-DX-048	SJ01-00018-000	Hydraulic Hose, 54.3"	1
49-2	TP10KAC-DX-049.2	SJ12-03000-A00	Mainside Carriage	1
49-3	TP10KAC-DX-049.3	SJ12-03000-A01	Offside Carriage	1
50	TP11KC-DX-050	SJ01-00020-000	Sliding Rub Block	16
51	TP11KC-DX-051	5304-00018-000	Circlips, D18	4
52	TP11KC-DX-052	SJ01-00024-000	Spring	4
53	TP11KC-DX-053	SJ01-00022-000	Gear Shaft, M16	4
54	TP11KC-DX-054	SJ01-00023-000	Small Gear	4
55	TP11KC-DX-055	5402-06038-000	Cotter Pin, D6 x 38mm	4
56-1	TP10KAC-DX-056.1	SJ01-12003-ETL	Anchor Bolt, 3/4" x 5-1/2"	12
57	TP11KC-DX-057	SJ01-12001-000	Elbow Fitting	1
58	TP11KC-DX-058	5901-00118-000	O-Ring, D11.8 x D1.8	1
59	TP11KC-DX-059	5103-08030-000	Bolt, M8 x 30mm	4
60-1	PU-220V SPX iDEAL	AC-10AH-RV21	SPX 220V Power Unit (ETL)	1
61-1	TP10KAC-DX-061.1	SJ12-05000-000	Mainside Bracket	1
62-1	TP11KAC-DX-062.1	SJ12-00002-B00	Spacer #1	2
63	TP11KC-DX-063	5301-00008-000	Washer, D8	9
65	TP11KC-DX-065	SJ01-00008-000	Elbow Fitting	2
66	TP11KC-DX-066	SJ01-12002-000	Shim	16
67	TP11KC-DX-067	SJ12-00017-A00	Height Adaptor Bracket	2
68	TP11KC-DX-068	SJ01-00030-000	Cover Plate, Limit Switch	1
69	TP11KC-DX-069	SJ03-00024-000	Cable Nut	1
70	TP11KC-DX-070	SJ01-00028-000	Housing, Limit Switch	1
71-1	TP11KC-DX-071.1	SJ01-00012-ETL	Limit Switch	1
72	TP11KC-DX-072	SJ03-00033-000	Bolt, M10 x 25mm	4
73	TP11KC-DX-073	SJ03-00018-001	Rubber Door Guard	2
74	TP11KC-DX-074	SJ12-09000-A00	LH & RH Rear Arm	2
75	TP11KC-DX-075	SJ01-00026-000	Jam Nut, Cylinder	2
76	TP11KC-DX-076	SJ01-00027-000	Hex Nut, Cylinder	2
77	TP11KC-DX-077	SJ03-15000-000	Cylinder	2
77-1	TP10KAC-DX-077.1	BL22-00002-000	Piston Rod	2
77-2	TP11KC-DX-077.2	5905-00200-000	Oil Seal, D28 x D20.5	2
77-3	TP11KC-DX-077.3	5901-00447-000	O-Ring, D44.7 x D3.5	2
77-4	TP11KC-DX-077.4	BL22-00003-000	Guide Ring	2
77-5	TP11KC-DX-077.5	BL22-00004-000	Circlip	2
77-6	TP11KC-DX-077.6	5906-00200-000	Dust Ring	2
77-7	TP11KC-DX-077.7	5312-00020-000	Circlip, D20 x D2	2
77-8	TP11KC-DX-077.8	5901-00200-000	O-Ring, D20 x D2.65	2
77-9	TP11KC-DX-077.9	BL22-00001-000	Piston	2
77-10	TP11KC-DX-077.10	5905-00410-000	Oil Seal, D50.8 x 41 x 7.3	4
77-11	TP11KC-DX-077.11	5904-00458-000	Guide Belt	2
77-12	TP11KC-DX-077.12	5202-00016-000	Nut, M16	2
77-13	TP11KC-DX-077.13	JP17-04004-000	Board	2
77-14	TP11KC-DX-077.14	QY02-02101-000	Spring	2
77-15	TP11KC-DX-077.15	SJ03-15002-000	Throttle Valve	2
77-16	TP11KC-DX-077.16	5308-00146-000	Washer	2
77-17	TP11KC-DX-077.17	SJ03-15001-000	Fitting Adaptor - A	2
77-18	TP11KC-DX-077.18	SJ01-03001-000	Fitting Adaptor - B	3
77-19	TP11KC-DX-077.19	SJ03-15100-000	Cylinder Body	2
80	TP11KC-DX-080	5102-10040-000	Bolt, M10 x 40mm	8
81	TP11KC-DX-081	SJ03-00031-000	Half Moon Gear	4

82	TP11KC-DX-082	SJ03-07000-001	LH Front Arm	1
83-1	TP11KC-DX-083.1	SJ03-00008-001	Rubber Pad	4
84-1	TP11KC-DX-084.1	SJ12-10100-000	Swivel Pad	4
86	TP11KC-DX-086	SJ12-07000-A00	Rear Arm Slider, End	2
87	TP11KC-DX-087	5202-00010-000	Nut, M10	4
88	TP11KC-DX-088	SJ01-00002-000	Equalizer Cable, 33'-8"	2
89	TP11KC-DX-089	5302-00016-000	Washer, D16	4
90	TP11KC-DX-090	5202-00016-000	Nut, M16	8
91	TP11KC-DX-091	SJ12-08000-A00	Front Arm Slider, End	2
92	TP11KC-DX-092	SJ03-07000-000	RH Front Arm	1
93	TP11KC-DX-093	SJ03-08000-000	Front Arm Slider, Middle	2
94	TP10KAC-DX-094	SJ01-00021-000	Swing Arm Pin	4
95	TP11KC-DX-095	5304-00014-000	Circlip, D14	4
96	TP11KC-DX-096	SJ01-00009-000	Sleeve	4
97	TP11KC-DX-097	SJ01-00013-000	Return Line #1	1
98	TP11KC-DX-098	SJ01-00010-000	Foam Rubber Tube	1
101	TP11KC-DX-101	5103-08040-000	Bolt, M8 x 40mm	1
103	TP11KC-DX-103	5120-08012-000	Screw, M8 x 12mm	4
104	TP11KC-DX-104	SJ16-00012-A00	Limit Block	2
106	TP11KC-DX-106	SJ12-00020-A00	Cable Lock	2
107	TP11KC-DX-107	SJ12-00021-A00	Turnbuckle	1
108	TP11KC-DX-108	SJ12-00022-A00	Hose Cover	1
109	TP10KAC-DX-109	5304-00038-000	Circlip, D38	4

6. Troubleshooting Guide

A.	Problem	Motor does not run.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Blown fuse or circuit breaker 2. Incorrect voltage to motor 3. Bad wiring connections. 4. Motor up switch burned out. 5. Overhead limit switch burned out. 6. Motor windings burned out. 	<ol style="list-style-type: none"> 1. Replace fuse or reset circuit breaker. 2. Supply correct voltage to motor. 3. Repair and insulate all connections. 4. Replace switch. 5. Replace switch. 6. Replace motor.
B.	Problem	Motor runs but lift will not raise.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Open lowering valve. 2. Pump sucking air 3. Suction stub off pump. 4. Low oil level 	<ol style="list-style-type: none"> 1. Repair or replace lowering valve. 2. Tighten all suction line fittings. 3. Replace suction stub. 4. Fill tank with Dexron III ATF
C	Problem	Lift will raise up only without load.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Motor running on low voltage 2. Debris in lowering valve. 3. Improper relief valve adjustment. 4. Overloading 	<ol style="list-style-type: none"> 1. Supply correct voltage to motor. 2. Clean lowering valve. 3. Replace relief valve cartridge. 4. Check or balance the vehicle weight on lift.
D	Problem	Lift slowly settles down.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Debris in check valve seat. 2. Debris in lowering valve seat. 3. External oil leaks 	<ol style="list-style-type: none"> 1. Clean check valve. 2. Clean lowering valve. 3. Repair external leaks.
E	Problem	Slow lifting speed or oil blowing out breather cap
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Air mixed with oil. 2. Air mixed with oil suction. 3. Oil over filled 	<ol style="list-style-type: none"> 1. Change oil to Dexron III ATF 2. Tighten all suction line fittings. 3. Only tap top the tank while arms are touching ground.
F	Problem	Lift going up unlevelled.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Equalizer cables out of adjustment. 2. Lift installed on unlevelled floor. 	<ol style="list-style-type: none"> 1. Adjust the length of the cables again. 2. Level the floor or level the column base by shims.
G	Problem	Anchors will not stay tight.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Holes drilled oversize. 2. Concrete floor thickness or holding strength not sufficient 	<ol style="list-style-type: none"> 1. Relocate lift using a new bit to drill holes. 2. Break out old concrete and pour new pads for lift per lift column
H	Problem	Locking latches do not engage.
	Possible cause:	Solution:
	<ol style="list-style-type: none"> 1. Latch shafts rusted. 2. Latch spring broken. 3. Latch cable needs adjustment. 	<ol style="list-style-type: none"> 1. Oil latch mechanism. Grease the shaft. 2. Replace broken spring. 3. Adjust clamps at cable end

7. Warranty Policy

LIMITED WARRANTY

Structural Warranty:

The following parts and structural components carry a five year warranty:

Columns	Arms	Uprights	Swivel Pins
Legs	Carriages	Overhead Beam	
Tracks	Cross Rails	Top Rail Beam	

Limited One-Year Warranty:

Tuxedo Distributors, LLC (iDEAL) offers a limited one-year warranty to the original purchaser of Lifts and Wheel Service equipment in the United States and Canada. Tuxedo will replace, without charge, any part found defective in materials or workmanship under normal use, for a period of one year after purchase. The purchaser is responsible for all shipping charges. This warranty does not apply to equipment that has been improperly installed or altered or that has not been operated or maintained according to specifications.

Other Limitations:

This warranty does not cover:

1. Parts needed for normal maintenance
2. Wear parts, including but not limited to cables, slider blocks, chains, rubber pads and pulleys
3. Replacement of lift and tire changer cylinders after the first 30 days. A seal kit and installation instructions will be sent for repairs thereafter.
4. On-site labor

Upon receipt, the customer must visually inspect the equipment for any potential freight damage before signing clear on the shipping receipt. Freight damage is not considered a warranty issue and therefore must be noted for any potential recovery with the shipping company.

The customer is required to notify Tuxedo of any missing parts within 72 hours. Timely notification must be received to be covered under warranty.

Tuxedo will replace any defective part under warranty at no charge as soon as such parts become available from the manufacturer. No guarantee is given as to the immediate availability of replacement parts.

Tuxedo reserves the right to make improvements and/or design changes to its lifts without any obligation to previously sold, assembled or fabricated equipment.

There is no other express warranty on the Tuxedo lifts and this warranty is exclusive of and in lieu of all other warranties, expressed or implied, including all warranties of merchantability and fitness for a particular purpose.

To the fullest extent allowed by law, Tuxedo shall not be liable for loss of use, cost of cover, lost profits, inconvenience, lost time, commercial loss or other incidental or consequential damages.

This Limited Warranty is granted to the original purchaser only and is not transferable or assignable.

Some states do not allow exclusion or limitation of consequential damages or how long an implied warranty lasts, so the above limitations and exclusions may not apply. This warranty gives you specific legal rights and you may have other rights, which may vary from state to state.

1905 N Main St Suite C, Cleburne, TX 76033
Ph 817-558-9337 / Fax 817-558-9740