

TIRE INFLATOR BLOCKHEAD

Branick[®]



**Remove the manual process
from tire inflation!**



The Branick BlockHead Auto Inflator removes the need for stick or hand-held gauges! The BlockHead has auto inflate and deflate capabilities with an audible beep to let you know the tire is ready. You just set the pressure, connect the chuck and the auto inflator does the rest. There are multiple ways to install the BlockHead including mounted on the wall direct from any air supply, utilizing existing hose reels, using a manifold for 4-6 tires simultaneously, or mounted on a tire safety cage. The BlockHead has a safety feature for high pressure tires and comes with an air chuck and fill hose. It is also nitrogen conversion ready and comes with a one year warranty.



**Mount to tire
safety cage**



**Utilize existing
hose reels**



**Manifold for
4-6 tires
simultaneously***
*Manifold and valve
kit required

FEATURES

- No stick/hand-held gauges.....
- Auto inflate and deflate without leaving....
- Simple touch-screen technology.....
- Multiple installation options.....
- Safety feature for high pressure tires.....
- Nitrogen conversion ready.....

BENEFITS

- No more wasted time!
- No more back and forth from valve stem tire stem
- Set pressure, connect chuck and BlockHead does the rest
- Versatile and easy to use
- Audible beep sounds when tire is ready
- One-stop for all your inflation needs



**Watch the video with
your SmartPhone!**